


**1** Cliquez sur la **CAMERA** pour trouver le support  
↓




**2** Click **HERE** pour voir tous les supports

## For DI-Fixed Lens & DV-Fixed Lens




# For DI-VF Lens, DI-MVF Lens & DH-Fixed Lens, DH-MVF Lens



## For DAI-Fixed Lens



\* Please remove the junction box cover **BEFORE** connect the camera to the junction box.




## For DAI-VF Lens, DAI-MVF Lens




\* Please remove the junction box cover **BEFORE** connect the camera to the junction box.



## For DMA



## For FEI



For DI-AB



For I1-AB



+


IP65



PR-B42PJB+



## For I5PT / I8PT





## For Bullet I6-VF Lens, I6-MVF Lens



+




+





# For I4-Fixed Lens, I4-VF Lens, I4-MVF Lens, BMV-Fixed Lens & BMH-Fixed Lens, BMH-MVF Lens



+



+



## For I2-Fixed Lens & BSV-Fixed Lens



+



+



## For PTZ-Z4




+



+





+



+

+




## For PTZ-Z5



+





+



+

+




## For PTZ-Z6



+





+



+

+



# Junction boxes



Model	Junction boxes	Installation
<b>Dome</b> DI-VF	<b>Wall A</b> PR-WB-A OR <b>IP66</b> PR-JB14IP66 <b>IP64</b> PR-JB14IP64	<b>Wall B</b> optional: PR-WB14, PR-B10EX <b>Ceiling</b> optional: PR-CB14, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-WB14 <b>Corner</b> optional: PR-B50ECB, PR-WB14
<b>Dome</b> DI-FIX	<b>Wall A</b> PR-WB-A OR <b>IP66</b> PR-JB12IP66 <b>IP64</b> PR-JB12IP64	<b>Wall B</b> optional: PR-WB12, PR-B10EX <b>Ceiling</b> optional: PR-CB12, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-WB12 <b>Corner</b> optional: PR-B50ECB, PR-WB12
<b>Dome</b> DAI-VF	<b>IP66</b> PR-JB14IP66 OR <b>Wall</b> optional: PR-WB14, PR-B10EX <b>Ceiling</b> optional: PR-CB14, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-WB14 <b>Corner</b> optional: PR-B50ECB, PR-WB14 OR <b>Ceiling</b> PR-ICB23	
<b>Dome</b> DAI-FIX	<b>Wall A</b> PR-WB-A OR <b>IP66</b> PR-JB12IP66 OR <b>Wall B</b> optional: PR-WB12, PR-B10EX <b>Ceiling</b> optional: PR-CB12, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-WB12 <b>Corner</b> optional: PR-B50ECB, PR-WB12 OR <b>Ceiling</b> PR-ICB21	
<b>Dome</b> DMA	<b>Wall A</b> PR-WB-A OR <b>IP66</b> PR-B10BJB OR <b>Wall B</b> optional: PR-WB12, PR-B10EX <b>Ceiling</b> optional: PR-CB12, PR-B10EX	
<b>Dome</b> FEI	<b>IP66</b> PR-B50JB OR <b>Wall</b> optional: PR-WB50, PR-B10EX <b>Ceiling</b> optional: PR-CB50, PR-B10EX	

**\* For DAI Installations, please remove the junctions box cover and connect the camera directly to the junction box**

Model	Junction boxes	Installation
<b>Bullet</b> I6	<b>IP66</b> PR-JB14IP66 <b>IP64</b> PR-JB14IP64	<b>Wall</b> optional: PR-WB14, PR-B10EX <b>Ceiling</b> optional: PR-CB14, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-CB14 <b>Corner</b> optional: PR-B50ECB, PR-CB14
<b>Bullet</b> I4	<b>IP66</b> PR-JB12IP66 <b>IP64</b> PR-JB12IP64	<b>Wall</b> optional: PR-WB12, PR-B10EX <b>Ceiling</b> optional: PR-CB12, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-CB12 <b>Corner</b> optional: PR-B50ECB, PR-CB12
<b>Bullet</b> I2	<b>IP66</b> PR-JB12IP66 <b>IP64</b> PR-JB12IP64	<b>Wall</b> optional: PR-WB12, PR-B10EX <b>Ceiling</b> optional: PR-CB12, PR-B10EX <b>Pole</b> optional: PR-B50PB, PR-CB12 <b>Corner</b> optional: PR-B50ECB, PR-CB12
<b>PTZ</b> Z4	<b>Wall</b> INCLUDED OR <b>Integrated Junction Box</b> PR-WJB-Z <b>Ceiling</b> PR-CB-Z <b>In-Ceiling</b> PR-ICB-Z <b>Pole</b> PR-B50PB INCLUDED <b>Corner</b> PR-B50ECB INCLUDED <b>Pole</b> PR-B60PB INCLUDED <b>Corner</b> PR-B60ECB INCLUDED <b>Integrated Junction Box</b> PR-WJB-Z	
<b>PTZ</b> Z5	<b>Wall</b> INCLUDED OR <b>Integrated Junction Box</b> PR-WJB-Z <b>Ceiling</b> PR-CB-Z <b>Pole</b> PR-B50PB INCLUDED <b>Corner</b> PR-B50ECB INCLUDED <b>Pole</b> PR-B60PB INCLUDED <b>Corner</b> PR-B60ECB INCLUDED <b>Integrated Junction Box</b> PR-WJB-Z	
<b>PTZ</b> Z6	<b>Wall</b> INCLUDED OR <b>Integrated Junction Box</b> PR-WJB-Z <b>Ceiling</b> PR-CB-Z <b>Pole</b> PR-B70PB INCLUDED <b>Corner</b> PR-B70ECB INCLUDED <b>Pole</b> PR-B60PB INCLUDED <b>Corner</b> PR-B60ECB INCLUDED <b>Integrated Junction Box</b> PR-WJB-Z	